

The Compatible Restorative Components listed below are those that fit directly to the implant. For example, the UCLA components (impression coping, UCLA abutment, and analog) for Branemark RP may also be used

with the Steri-Oss Hex-Lock 3.8 & 4.5, Restore RD, etc. The external configuration of the compatible implants may differ, but the fitting surface and internal threads are compatible.

Implants	Restoratively Compatible To	Implants	Restoratively Compatible To
<b>Branemark NP</b> 3.3 external hex - 3.5 Platform	Branemark MK III & IV 3.3 Implanted NP	<b>Restore SD</b> threaded or cylinder ex hex 3.3 or 3.4	<b>Sustain SD</b> 3.4
<b>Branemark RP</b> 3.7 & 4.0 external hex - 4.1 Platform	Branemark MK III & IV 3.75 & 4.0 NobelSpeedy Groovy NobelSpeedy Groovy Shorty 3i Miniplant & Standard 3.75 & 4.0 Implanted RP IMZ Hex Head 3.3 & 4.0 Innova Entegra 3.25 & 4.0 Osteo Implant 3.75 Restore RD & Sustain RD Steri-Oss Hex-Loc 3.8 & 4.5 Swede-Vent 3.75 Taper-Lock Threadloc	<b>Sustain SD</b> threaded or cylinder ex hex 3.3 or 3.4	Restore SD 3.3
<b>Branemark WP</b> 5.0 & 5.5 external hex - 5.1 Platform	Branemark MK III & IV 5.0 Implanted WP	<b>Restore RD</b> threaded or cylinder ex hex 3.75 or 4.0	<b>Branemark, Regular Platform 4.1</b>
<b>IMZ Original</b> 3.3 & 4.0 non-hex	none	<b>Sustain RD</b> threaded or cylinder ex hex 3.75, 4.0, 4.2	<b>Branemark, Regular Platform 4.1</b>
<b>IMZ Hex Head</b> 3.3 & 4.0 external hex	<b>Branemark, Regular Platform 4.1</b>	<b>Stage-1</b> internal locking Morse taper	Straumann ITI
<b>ITI Small Diameter</b> external hex	none	<b>Sustain</b> internal bevel cylindrical 3 diameters	none
<b>ITI Standard</b> 4.8 internal Morse taper	LifeCore Stage-1 3i TG Osseotite	<b>Screw-Vent SD, Core-Vent SD, Micro-Vent, Bio-Vent</b> 3.5	MV 3.25, SV 3.7 & 3.75, BV 3.5, ADI 3.5
<b>ITI Syn-Octa</b> 4.8 internal octagomorfice taper	Paragon SwissPlus, Blue Sky Bio	<b>Screw-Vent MD, Core-Vent SD, Micro-Vent, Bio-Vent</b> 4.5	MV 4.25 & 4.7, SV 4.7, BV 4.5, ADI 4.5
<b>Integral SD</b> 3.25 non-hex flat-top	O-Butment 3.25	<b>Screw-Vent WD</b> 5.7 - 6.0 Platform	none
<b>Integral</b> 4.0 non-hex flat-top	O-Butment / Anchor 4.0	<b>Taper-Lock</b> external hex - 4.1 Platform	<b>Branemark, Regular Platform 4.1</b>
<b>Omniloc</b> 3.25 & 4.0	Steri-Oss Original 4.0 non-hex	<b>SwissPlus</b>	ITI Syn-Octa 4.8, Blue Sky Bio
<b>Threadloc</b> 3.75 external hex	none	<b>Steri-Oss Original</b> 3.25 non-hex flat-top	none
<b>Calcitek Spine SD, RD &amp; WD</b>	none	<b>Steri-Oss Original</b> 3.5, 3.8 and 4.0 non-hex flat-top	O-Butment / Anchor 4.0 Integral 4.0
<b>3i Microminiplant</b> 3.25 external hex 3.4 platform	none	<b>Steri-Oss Hex-Loc</b> 3.25	none
<b>3i Miniplant</b> 3.25 external hex 4.1 platform	<b>Branemark, Regular Platform 4.1</b>	<b>Steri-Oss Hex-Loc</b> 3.8 & 4.5	<b>Branemark, Regular Platform 4.1</b>
<b>3i Standard</b> 3.75 external hex 4.1 platform	<b>Branemark, Regular Platform 4.1</b>	<b>Steri-Oss Replace 3.5 &amp; 4.3</b> external hex	none
<b>3i Wide Diameter</b> 5.0 external hex 5.0 platform	none	<b>Steri-Oss Replace 5.0</b> external hex	Steri-Oss HexLoc 5.0
<b>3i Wide Diameter</b> 6.0 external hex 6.0 platform	none	<b>Steri-Oss Select</b> internal connection	NobelReplace Tapered Groovy NobelSpeedy Replace NobelReplace Straight
<b>3i Osseotite TG</b> internal Morse taper	Straumann ITI Standard 4.8 internal	<b>Blue Sky Bio</b> Narrow 3.3, 4.1 internal taper connection Regular 3.3, 4.1, 4.8 internal taper connection Wide 4.8, 5.6 internal taper connection	Straumann ITI, LifeCore Stage-1 Straumann synOcta
		<b>Blue Sky Bio Trilobe</b> internal tri-channel connection (coming soon)	NobelReplace internal tri-channel

**Branemark  
Nobel Biocare**

**IMZ**

**ITI  
Straumann**

**Integral  
Zimmer**

**3i Implant Innovations  
Biomet**